

**Momentive's SilGrip PSA6573A** is a heat-assisted, high shear silicone contact adhesive that becomes aggressively pressure sensitive at 93°C (200°F) but is almost tack-free at room temperature. Maintaining flexibility and adhesion to difficult substrates under extremely harsh conditions is aided by the adhesive's silicone backbone.



### SilGrip PSA6573A Technical Features



**Good shear and peel strength**



**Excellent adhesion, including to low surface energy materials**



**Stability in harsh environments**



**Wide operating temperature range**



**Chemical, moisture and weathering resistance**



**Good electrical insulation properties**



**High oxygen permeability**

**Use as an alternative to:**

- Fasteners
- Urethanes
- Epoxies
- Rubber cement
- Spray adhesives

### Basic Uses

SilGrip PSA6573A offers a range of uses where high performance adhesive is required, such as freezer components, and applications for outdoor exposure, aerospace and flexible substrates. It is also be used in general assembly applications to laminate and bond a variety of substrates, including silicone, glass cloth, aluminum and carbon fibers.

### Typical Physical Properties

Cured properties	3.3% SilGrip SRC18
Probe tack, g/cm <sup>2</sup>	200 max.
Peel strength, g/in (180° peel at 12 in/min)	2,200
Viscosity at 25°C (77°F), cps Brookfield RVF, #6 spindle, 20 rpm	19,000
% solids	60%
Flash point, TCC °C (F)	4 (40)
Solvent	Toluene

Typical properties are average data and are not to be used as or to develop specifications.

## Preparation and Application of SilGrip\* PSA6573A using SilGrip SRC18 Catalyst

SilGrip PSA6573A catalyzed with SilGrip SRC18 is used to bond a variety of materials, including silicone, aluminum, carbon fiber, glass cloth, as well as many other substrates. Before you begin to mix the PSA with the catalyst, please be sure to review each product's Safety Data Sheet. Remember to work in a well-ventilated area and follow all appropriate safety protocols.

### Things you will need to apply SilGrip PSA6573A:

- SilGrip PSA6573A
- SilGrip SRC18
- A cup or container
- A stick to mix the materials together
- A scale
- A roller, brush or other suitable coating tool
- A cloth or towel to clean the substrates to be bonded
- An appropriate solvent for cleaning

### General Instructions

- Step 1:** Clean and dry all surfaces to be bonded. A lint free towel and an appropriate solvent can be used to remove all grease, oil and debris.
- Step 2:** Combine the PSA with the catalyst using the following typical product blending ratio - SilGrip PSA6573A 100 parts by weight to SilGrip SRC18 3.3 parts by weight.
- Step 3:** Turn on your scale. Place the cup or container on the scale. Zero out the scale.
- Step 4:** Pour SilGrip PSA6573A into cup or container on scale. Once complete, zero out the scale again.
- Step 5:** Add SilGrip SRC18 to the SilGrip PSA6573A - pour 3.3 parts per weight of SilGrip SRC18 into the SilGrip PSA6573A. You may want to pre-pour your components or use a medicine dropper for the SilGrip SRC18.
- Step 6:** Stir the liquid thoroughly until the SilGrip SRC18 is well mixed with the SilGrip PSA6573A
- Step 7:** Apply the adhesive to 1 of the 2 substrates to be bonded using your brush, roller or suitable coating tool. Thinning, if required, may be done with toluene or paint thinner.
- Step 8:** Before assembling the pieces, you must allow for the thinner in the adhesive to evaporate. This is known as drying time. The length of drying time will depend on the thinner used, adhesive thickness, and temperature. A good starting point is 20 minutes. A heat gun could also be used to speed up drying time.
- Step 9:** After 20 minutes, check the substrate. It should be tacky.
- Step 10:** If the solvent is evaporated from the adhesive, the surfaces to be bonded should be firmly pressed together and the adhesive allowed to cure. The recommended adhesive thickness is 3 to 4 mils when dry.

Cure is a function of time and temperature. Room temperature cure at 21°C to 25°C (70°F to 77°F) will require 3 to 7 days for the catalyzed adhesive to develop maximum strength. The cure time can be shortened by elevating temperature to a maximum of 165°C (329°F). A typical shortened cure cycle is 24 hours at 25°C (77°F) followed by 24 hours at 100°C (212°F).

If there is any leftover catalyzed adhesive, store it in tightly closed containers and use within 48 hours.

#### Distributed by:

Momentive, the Momentive logo and any terms followed by a \* are trademarks of Momentive Performance Materials Inc. or its affiliates.

2020 Momentive Performance Materials Inc. All rights reserved.

Although any information, recommendations, or advice contained herein is given in good faith, Momentive makes no warranty or guarantee, express or implied, (i) that the results described herein will be obtained under end-use conditions, or (ii) as to the effectiveness or safety of any design incorporating suppliers' products, materials, services, recommendations or advice. For complete terms and conditions, visit: [www.momentive.com/terms-of-use/legal-disclaimer](http://www.momentive.com/terms-of-use/legal-disclaimer).