



Barrel Cleaner (For Guns & Rifles)

WT %

69.0 SoyGold 1000

15.0 Glycol Ether EB

7.5 140 Solvent High Flash (Shell)

7.0 Igepal CO-630 (Rhodia)

1.5 Diethanolamine (DEA)

Blending Procedure:

1. To a clean dry processing vessel, add 140 solvent, Igepal CO-630, EB, and DEA.
2. Mix until the product is clear and uniform.
3. With agitation, slowly introduce the SoyGold 1000.
4. Mix until uniform.

The information given in this formulary is to the best of our knowledge accurate. The formulations are intended to be helpful, but no warranty is expressed or implied regarding the accuracy of the data. It is the users responsibility to determine the suitability of his use of the products described herein, and since the conditions of use are out of our control, we disclaim all liability with respect to the use of any materials supplied by AEP. Nothing contained herein shall be construed as permission or as a recommendation to practice any patented invention without a license from the patent owner nor as a recommendation to use any product or to practice any process in violation of any law or any government regulations.