

High SPF sunscreen spray with Eastman AQ™ 38S polymer

SPF 50¹ sunscreen spray

Part A: Water Phase	wt %
Deionized water	51.32
Glycerin	3.00
Amphisol™ K Potassium Cetyl Phosphate ²	2.50
Disodium EDTA	0.05
Eastman AQ™ 38S Polyester-5	3.00
Part B: Oil Phase	
Crodamol™ AB C12–15 Alkyl Benzoate ³	5.00
Parsol™ MCX Ethylhexyl Methoxycinnamate ²	7.50
Parsol™ 340 Octocrylene ²	4.00
Uvinul™ M 40 Benzophenone-3 ⁴	6.00
Z-Cote™ HP 1 Zinc Oxide (and) Triethoxycaprylylsilane ⁴	1.43
Neo Heliopan™ HMS Homosalate ⁵	8.00
Eusolex™ OS Ethylhexyl Salicylate ⁶	5.00
Cutina™ GMS V Glyceryl Stearate ⁷	2.00
Lanette™ O Cetearyl Alcohol ⁷	1.20
Part C: Preservative	
Preservative	q.s. ⁸

¹SPF determined by in vivo testing ²DSM ³Croda ⁴BASF

⁵Symrise ⁶Merck ⁷Cognis ⁸Quantity sufficient

Part A

- Combine all Part A ingredients, except Eastman AQ™ 38S polymer, and heat to 75°C with stirring.
- Add Eastman AQ™ 38S polymer pellets at 75°C; continue stirring until pellets are completely dispersed.

Part B

- Combine Part B ingredients.
- Heat to about 85°C, stirring continually until mixture is completely dissolved.

With Part A at 75°C and Part B at 85°C, gradually add Part B to Part A with rapid stirring. Continue stirring until combined Parts A and B pre-emulsion is homogenous.

Homogenize^a combined Parts A and B pre-emulsion at high speed for 10 minutes with no additional heating; cover container to prevent water loss.

With stirring, cool combined Parts A and B emulsion to 40°C or less.

Part C

- Add preservative at 40°C or less with stirring.

If necessary, adjust pH to 6.0–7.0 with dilute sodium hydroxide solution.

^aSuitable laboratory homogenizers include rotor-stator, slotted-head mixers — with a head diameter of 4.5 cm or more — available from Silverson Machines, Inc. or Janke & Kunkel.

The mean particle diameter of this homogenized emulsion is about 0.7–1.2 micron, which is in a desired range for formula stability. Since homogenizer type, homogenizer head design, and rotor speed may produce different mean particle sizes, it is up to the formulator to obtain their required particle size.

Eastman Chemical Company

Corporate Headquarters

P.O. Box 431
Kingsport, TN 37662-5280 U.S.A.
Telephone:
U.S.A. and Canada, 800-EASTMAN
(800-327-8626)
Other Locations (1) 423-229-2000
Fax: (1) 423-229-1193
www.eastman.com

Eastman Chemical Latin America

9155 South Dadeland Blvd.
Suite 1116
Miami, FL 33156 U.S.A.
Telephone: (1) 305-671-2800
Fax: (1) 305-671-2805

Eastman Chemical B.V.

Fascinatio Boulevard 602-614
2909 VA Capelle aan den IJssel
The Netherlands
Telephone: (31) 10 2402 111
Fax: (31) 10 2402 100

Eastman Chemical Japan, Ltd.

AIG Aoyama Building 5F
2-11-16 Minami Aoyama
Minato-ku, Tokyo 107-0062 Japan
Telephone: (81) 3-3475-9510
Fax: (81) 3-3475-9515

Eastman Chemical Asia Pacific, Pte. Ltd.

#05-04 Winsland House
3 Killiney Road
Singapore 239519
Telephone: (65) 6831-3100
Fax: (65) 6732-4930

It is the responsibility of the cosmetic formulator or manufacturer to determine the suitability of all raw materials, including any Eastman product used in its final product in order to ensure safety and compliance with requirements of all appropriate U.S. and international regulatory agencies.

Material Safety Data Sheets providing safety precautions, that should be observed when handling and storing Eastman products, are available online or by request. You should obtain and review the available material safety information before handling any of these products. If any materials mentioned are not Eastman products, appropriate industrial hygiene and other safety precautions recommended by their manufacturers should be observed.

Neither Eastman Chemical Company nor its marketing affiliates shall be responsible for the use of this information, or of any product, method or apparatus mentioned, and you must make your own determination of its suitability and completeness for your own use, for the protection of the environment and for the health and safety of your employees and purchasers of your products. NO WARRANTY IS MADE OF THE MERCHANTABILITY OR FITNESS OF ANY PRODUCT, AND NOTHING HEREIN WAIVES ANY OF THE SELLER'S CONDITIONS OF SALE.

Eastman and Eastman AQ are trademarks
of Eastman Chemical Company.

© Eastman Chemical Company, 2008.